

ULTRAHUND “TRUE-FIT” BUCKLE COLLAR SIZING


The Ultrahund collar is a “true-fit” collar. Each Ultrahund buckle collar has five sizing holes. Collar size is based on the length from the center hole (3rd hole) of the collar to buckle prong.

What does this mean?

It means that simply by measuring the circumference of your dog’s neck, you can select the correct size Ultrahund buckle collar.


As an example, if the circumference of your dog’s neck is 18 inches, you would select the Ultrahund 18 inch collar. The 18 inch collar will fit a dog whose neck size is between 16 inches and 20 inches because the first of the five holes is located 16 inches from the buckle prong and the last hole of the five holes is located 20 inches from the buckle prong. There is one inch spacing between each of the five holes on every 1 inch wide buckle collar. See sample diagram of the Ultrahund 18 inch collar below:

Ultrahund 18" Collar - Fits Dog Neck circumference 16 inches to 20 inches



Similarly, using the ¾ inch wide collar, if your dog’s neck circumference is 14 inches, you would select the Ultrahund 14 inch collar. On the ¾ inch wide collar, the five holes are ¾ inches apart. This means that the 14 inch collar will fit a dog whose neck size is between 12-1/2 inches to 15-1/2 inches. At 14 inches, the buckle prong would protrude through the center hole. See sample diagram of the Ultrahund 14 inch collar below:

Ultrahund 14" Collar - Fits Dog Neck circumference 12.5 inches to 15.5 inches



Other Import Sizing Considerations

All Ultrahund buckle collars are made with a PVC outer coating and an imbedded nylon mesh, stitched (not riveted) at all stress points. This provides a soft (leather-like) feel, yet exceedingly strong design. However, careful consideration must be made with regard to your dogs breed, weight and temperament before selecting the right collar for your dog. The ¾ inch wide collars use a 1.5 mm thick substrate material and comes in standard 10", 12" 14" and 16" “true-fit” lengths. The ¾ inch wide collars are **generally** applicable for dogs weighing 30 pounds or less.

The 1 inch wide collars use a 2.5 mm thick substrate and come in standard 18", 20", 22" and 24" “true-fit” lengths. The 1 inch wide collars are **generally** applicable for dogs weighing 25 pound to 80 pounds. However, care must be taken to ensure the collar chosen is right for your dog. The neck size should not be your only consideration. Dog strength, breed, pull and temperament should also be considered. See chart below for applicable collar sizes.

Ultrahund "True-Fit" Buckle Collar Sizing Chart

Three-Quarter Inch (19mm) Wide "Play Regular" Collars - Small

True-Fit Size	Fits neck size circumference Imperial	Fits neck size circumference Metric	Thickness	General Weight / Limit Recommendation
10 Inches (25 cm)	8.5" to 11.5"	22 cm to 29 cm	1.5 mm	Up to 30 pounds (13 kg)
12 Inches (30 cm)	10.5" to 14.5"	26 cm to 37 cm	1.5 mm	Up to 30 pounds (13 kg)
14 Inches (36 cm)	12.5" to 15.5"	31 cm to 39 cm	1.5 mm	Up to 30 pounds (13 kg)
16 Inches (41 cm)	14.5" to 17.5"	36 cm to 44 cm	1.5 mm	Up to 30 pounds (13 kg)

One Inch (25mm) Wide "Play Regular" Collars - Large

True-Fit Size	Fits neck size circumference Imperial	Fits neck size circumference Metric	Thickness	General Weight / Limit Recommendation
18 Inches (46 cm)	16" to 20"	41 cm to 51 cm	2.5 mm	25 pounds (11 kg) to 80 pounds (36 kg)
20 Inches (51 cm)	18" to 22"	46 cm to 56 cm	2.5 mm	25 pounds (11 kg) to 80 pounds (36 kg)
22 Inches (56 cm)	20" to 24"	51 cm to 61 cm	2.5 mm	25 pounds (11 kg) to 80 pounds (36 kg)
24 Inches (61 cm)	22" to 26"	56 cm to 66 cm	2.5 mm	25 pounds (11 kg) to 80 pounds (36 kg)

Ultrahund Play Adjustable Collar Sizing Chart

Three-Quarter Inch (19 mm) Wide "Play Adjustable" Collars - Small

Size	Fits neck size circumference Imperial	Fits neck size circumference Metric	Thickness	General Weight / Limit Recommendation
Small Adjustable	12" to 16"	31 cm to 41 cm	1.0 mm	Up to 30 pounds (13 kg)

1 Inch (25 mm) Wide "Play Adjustable" Collars - Large

Size	Fits neck size circumference Imperial	Fits neck size circumference Metric	Thickness	General Weight / Limit Recommendation
Large Adjustable	16" to 22"	41 cm to 56 cm	2.0 mm	25 pounds (11 kg) to 80 pounds (36 kg)

Ultrahund Martingale Collar Sizing Chart

Three-Quarter Inch (19 mm) Wide "Play Martingale" Collars - Small

Size	Fits neck size circumference Imperial	Fits neck size circumference Metric	Thickness	General Weight / Limit Recommendation
Small Adjustable	14" to 18"	36 cm to 46 cm	1.0 mm	Up to 30 pounds (13 kg)

1 Inch (25 mm) Wide "Play Martingale" Collars - Large

Size	Fits neck size circumference Imperial	Fits neck size circumference Metric	Thickness	General Weight / Limit Recommendation
Large Adjustable	18" to 22"	46 cm to 56 cm	2.0 mm	25 pounds (11 kg) to 80 pounds (36 kg)

Ultrahund "Freedom" Harness Sizing Chart

Size	Material Substrate width Imperial	Material Substrate width Metric	Thickness	General Weight / Limit Recommendation
X-Small Adjustable	5/8"	16 mm	1.0 mm	Up to 10 pounds (4 kg)
Small Adjustable	5/8"	16 mm	1.0 mm	Up to 25 pounds (11 kg)
Medium Adjustable	3/4"	19 mm	1.5 mm	Up to 60 pounds (27 kg)
Large Adjustable	1"	25 mm	1.5 mm	Up to 130 pounds (59 kg)